

INSTANT FILTER CLEANER



Instant Filter Cleaner quickly removes debris, oils, body fats and dirt utilising a unique “No Soak” formula. This product is suitable for use on both hot tub and swimming pool cartridge filters.

GENERAL INSTRUCTIONS

1. Wear protective gloves and use outdoors/well ventilated area. Avoid use on windy days.
2. Remove filter/s from the filter compartment.
3. Rinse the filter/s with fresh water, a hose pipe is ideal to remove loose pollution from the filter.
4. Turn the nozzle on the trigger spray applicator from the STOP to SPRAY position.
5. Thoroughly spray the filter with Instant Filter Cleaner taking care to penetrate the filter veins with product. After use turn the nozzle of the spray applicator from SPRAY to STOP and store the bottle safely.
6. Leave the filter/s to stand for a minimum 15 minutes.
7. Rinse the filter/s thoroughly with fresh water from a hose pipe – at this stage foaming may occur. Continue rinsing until foaming stops.
8. Heavily soiled filters may require a second application.
9. Once the filters have been thoroughly cleaned and flushed, they can be returned to the filter compartment of your pool, hot tub, or spa.

PLEASE NOTE: Instant Filter Cleaner should be used on a weekly basis to ensure that your filters work to maximum efficiency.

For further information go to our website www.lo-chlor.co.uk.